

Front panel

Pic: 1

ARAT navigation
mount

Adapter

Side view
Front panel

Locating
tongue

ARAT
Mount

Pic: 2

ARAT
mount

Airvanes

Supplied
screw
2.9 x 13

Installation instruction

Place the airvanes into the flat horizontal position
place the ARAT mount in the airvent so that the mount
slides between the airvanes, and the small locating tongue
snaps into position behind the front panel (see Pic:1 + Pic:2)
securing the mount with the supplied screw (2.9 x 13) through
the airvane and screw into the material underneath the mount
(pre-drill the airvane $\varnothing$ 3mm)